

UNIT TEMPERATURE CONTROL

Une seule unité de contrôle dans l'entrée avec des sorties d'air dans chacune des pièces

Note : Certaines chambres (Beauvallon, Toboggan, Alpine) peuvent être plus froides et des calorifères d'appoints sont installés avec des contrôles NEST pour un meilleur confort.

Attention : Ne pas climatiser avec le système central et chauffer avec les unités d'appoint dans les chambres, car cela crée une boucle sans fin de correction de température.


Au besoin : Ajuster les trappes de sortie d'air des pièces pour aider la circulation d'air et l'ajustement de température.

A single control unit in the entrance with air outlets in each of the rooms

Note: Some rooms (Beauvallon, Toboggan, Alpine) may be colder and additional heaters are installed with NEST controls for better comfort.

Warning: Do not air conditioning with the central system and heat with the extra units in the bedrooms, as this creates an endless loop of temperature correction.

As needed: Adjust room exhaust vents to aid airflow and temperature adjustment.



Le système est déjà programmé pour les différentes saisons et pour les périodes de la journée. **NE JAMAIS TOUCHER OU CHANGER LA CONFIGURATION.**

The system is already programmed for the different seasons and for the times of the day. **NEVER TOUCH OR CHANGE THE CONFIGURATION.**

Appuyer sur le bouton PLUS ou MOINS pour ajuster la température selon votre besoin sans exagération. Garder en tête que la température reviendra ensuite au niveau selon le programme prévu.

Press the PLUS or MINUS button to adjust the temperature as needed without exaggeration. Keep in mind that the temperature will then return to the level according to the schedule.